

BANNER INSTALLATION

- Pull the attaching ropes horizontally as illustrated on the right side of the banner. Do not pull at an angle as illustrated on the left side (Top Diagram).
- Periodically check the installation and take up any slack in the ropes.
- For large banners and/or banners that span long distances, say over 8 feet, use a second set of ropes to suspend the banner and distribute the load, as illustrated below (Bottom Diagram).

If you follow these simple tips, your banner will have a longer life.

